



Original	Replacement	Original	Replacement
 Power	 Power	 Right	 Right
 Mute	 Mute	 Down	 Down
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Ch. List	 Smart
 4	 4	 Exit	 Exit
 5	 5	 Vol +	 Vol +
 6	 6	 Vol -	 Vol -
 7	 7	 Sound	 Shift + Dual
 8	 8	 Ch +	 Ch +
 9	 9	 Ch -	 Ch -
 0	 0	 PIC	 Shift + Format
 Audio	 Dual	 Text	 Text
 Recall	 Back	 Aspect	 Format
 TV Menu	 Menu	 Freeze	 Pause
 Source	 AV	 EPG	 Guide
 Up	 Up	 Sleep	 Sleep





Original		Replacement		Original		Replacement	
	TV / RADIO		TV/R				
	Info		Info				
	FAV		Pre Ch				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Reveal		Media				
	Hold		Stop				
	List		List				
	Subpage		<<				
	Size		Eject				
	Mix		>>				
	Subtitle		Subt				
	Index		Play				

