







































































| Original | Replacement | Original | Replacement |
|-------------|---|------------|---|
| On/Off |  Power | Menu Right |  Right |
| Mute |  Mute | Menu Off |  Exit |
| Update |  Media | Menu Down |  Down |
| Reveal |  Smart | Back |  Back |
| Txt Stop |  Stop | Volume+ |  Vol + |
| Subt.List |  Subt | Chan.Up |  Ch + |
| Sleep Timer |  Sleep | Volume- |  Vol - |
| Return TV |  TV/R | Menu audio |  Dual |
| Menu video |  D. Menu | Chan.Down |  Ch - |
| Text |  Text | 1 |  1 |
| Txt Expand |  Eject | 2 |  2 |
| TV/AV |  AV | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |
| OK Enter |  Ok | 8 |  8 |






















| Original | Replacement | Original | Replacement |
|---------------|--|----------|-------------|
| 9 |  9 | | |
| Guide -/-- 1. |  Guide | | |
| 0/10 |  0 | | |
| 2.Fav P/C 2. |  Pre Ch | | |
| Red |  Red | | |
| Green |  Green | | |
| Yellow |  Yellow | | |
| Blue |  Blue | | |
| 4.# 16:9 |  Format | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |



| Original | Replacement | Original | Replacement |
|--------------|---|------------|---|
| On/Off |  Power | OK Enter |  Ok |
| Audio Off |  Mute | Return |  Back |
| Slow Down |  I<< | Menu Right |  Right |
| Subt. |  Subt | Menu Down |  Down |
| Auto/Track |  Green | Volume+ |  Vol + |
| Slow Up |  >>I | Progr. |  Sleep |
| Rep/A-B |  +  Shift + Text | Next |  Ch + |
| Stop |  Stop | Volume- |  Vol - |
| Title |  List | Top Menu |  D. Menu |
| Zoom |  +  Shift + Eject | Prev. |  Ch - |
| Repeat/1/All |  Text | 1 |  1 |
| Pause |  Pause | 2 |  2 |
| DVD/TV |  AV | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Replacement | Original | Replacement |
|-------------|---|----------|---|
| 8 |  | 8 | |
| 9 |  | 9 | |
| +10 |  | Guide | |
| EQ |  | Media | |
| 0 |  | 0 | |
| C/CH |  | Pre Ch | |
| Digest |  | Red | |
| Record |  | Rec | |
| Open/Close |  | Eject | |
| Mode |  | Smart | |
| Angle |  | TV/R | |
| Rewind |  | << | |
| Play |  | Play | |
| Clear/00:00 |  | Exit | |
| Audio |  | Dual | |
| F.Forward |  | >> | |
| NTSC/PAL |  | Format | |
| | | Setup |  Options |
| | | 3D |  3D |

