



Original	Replacement
	 Power
	 Mute / Dimmer
	 Text / Goto
	 Subtitle / EQ
	 Audio / Lang I/II
	 Sleep / Timer
	 Shift + 1
	 Rec / Rec Mode
	 Stop / Hold
	 TV/Radio /
	 << / Tune-
	 Play / Slow
	 Pause / Step / Freeze
	 >> / Tune+
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat

Original	Replacement
	 Blue / Prime Video / Random
	 Menu / Home
	 Up
	 Exit / Cancel / Clear
	 Left
	 OK
	 Right
	 Guide / EPG / -/-
	 Down
	 Display / Media
	 Vol-
	 Vol+
	 Info / Angle
	 CH+ / Page+
	 CH- / Page-
	 Smart / List
	 1



