









Original		Replacement		Original		Replacement	
	Power		Power		Green		Green
	1		1		Yellow/FAV+		Yellow
	2		2		Blue		Blue
	3		3		White/FAV-		Media
	4		4		Pause		Pause
	5		5		Mute		Mute
	6		6		Menu		Menu
	7		7		Exit		Exit
	8		8		PR+		Ch +
	9		9		PR-		Ch -
	0		0		Up		Up
	Info		Info		Down		Down
	UHF		AV		Right		Right
	Audio		Dual		Left		Left
	Text		Text		OK		Ok
	Sat/TV		Subt		Vol+		Vol +
	Red		Red		Vol-		Vol -



