







































































| Original  | Replacement | Original  | Replacement           |
|---|-------------|---|-----------------------|
|    | Power       |    | Power                 |
|    | Mute        |    | Mute / Dimmer         |
|    | Source      |    | AV / Input / RDS      |
|    | I/II/Audio  |    | Audio / Lang I/II     |
|    | 1           |    | 1                     |
|    | 2           |    | 2                     |
|    | 3           |    | 3                     |
|    | 4           |    | 4                     |
|    | 5           |    | 5                     |
|    | 6           |    | 6                     |
|    | 7           |    | 7                     |
|  | 8           |  | 8                     |
|  | 9           |  | 9                     |
|  | 0           |  | 0                     |
|  | Menu        |  | Menu / Home           |
|  | Info        |  | Info / Angle          |
|  | Exit        |  | Exit / Cancel / Clear |

| Original  | Replacement   | Original  | Replacement                 |
|---|---------------|---|-----------------------------|
|    | Sleep         |    | Sleep / Timer               |
|    | Jump          |    | Display / Media             |
|    | FAV.CH        |    | Fav / Marker / PC           |
|    | OK            |    | OK                          |
|    | Up            |    | Up                          |
|    | Down          |    | Down                        |
|    | Left          |    | Left                        |
|    | Right         |    | Right                       |
|    | Vol+          |    | Vol+                        |
|    | Vol-          |    | Vol-                        |
|    | PR-           |    | CH- / Page-                 |
|  | PR+           |  | CH+ / Page+                 |
|  | Red/D.Setup   |  | Red / Netflix / Search      |
|  | Green/Repeat  |  | Green / APP / Repeat        |
|  | Yellow/Zoom   |  | Yellow / YouTube / Repeat   |
|  | Blue/Goto     |  | Blue / Prime Video / Random |
|  | [+]/DTV/Radio |  | TV/Radio /                  |



