



Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	Recall		Back
	Vol+		Vol +
	Vol-		Vol -
	Nicam		Dual
	Sleep		Sleep
	Display		Info
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Aspect		Format
	Source		AV
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Exit		Exit
	Menu		Menu
	Media		Media
	Play / Pause		Play





Original		Replacement		Original		Replacement	
	Play / Pause		Pause		Yellow		Yellow
	I<<		I<<		Blue		Blue
	>>I		>>I				
	Rec		Rec				
	Stop / Hold		Stop				
	<< / Index		<<				
	>> / Size		>>				
	Text		Text				
	FAV		Pre Ch				
	FAV-	 + 	Shift + Down				
	FAV+	 + 	Shift + Up				
	Reveal		Smart				
	Cancel	 + 	Shift + Exit				
	Subpage	 + 	Shift + Subt				
	Subtitle		Subt				
	Red / TV/Radio		Red				
	Green		Green				

