





































| Original  | Replacement | Original  | Replacement                 |
|---|-------------|---|-----------------------------|
|    | Power       |    | Green / APP / Repeat        |
|    | DTV         |    | Yellow / YouTube / Repeat   |
|    | TV          |    | Blue / Prime Video / Random |
|    | AV          |    | Vol+                        |
|    | 1           |    | Info / Angle                |
|    | 2           |    | CH+ / Page+                 |
|    | 3           |    | Vol-                        |
|    | 4           |    | Mute / Dimmer               |
|    | 5           |    | CH- / Page-                 |
|    | 6           |    | Guide / EPG / -/--          |
|   | 7           |   | Setup / OPT /               |
|  | 8           |  | Up                          |
|  | 9           |  | Left                        |
|  | Text        |  | OK                          |
|  | 0           |  | Right                       |
|  | PRE-CH      |  | Down                        |
|  | Red         |  | Menu / Home                 |





|  | Original   | Replacement   | Original | Replacement |
|--|--|---|----------|-------------|
|  |  Exit           |  Exit / Cancel / Clear       |          |             |
|  |  <<             |  << / Tune-                  |          |             |
|  |  Play           |  Play / Slow                 |          |             |
|  |  >>             |  >> / Tune+                  |          |             |
|  |  Rec            |  Rec / Rec Mode              |          |             |
|  |  Pause          |  Pause / Step / Freeze       |          |             |
|  |  Stop           |  Stop / Hold                 |          |             |
|  |  File List/[≡i] |  Smart / List                |          |             |
|  |  Bookmark/[.,≡] |  Display / Media             |          |             |
|  |  Repeat/[≡O]    |  Shift + Green / APP /       |          |             |
|  |  A<>B/[≡?]     |  Shift + Yellow / YouTube / |          |             |
|  |  PIC Size     |  Zoom / Size               |          |             |
|  |  PIC Mode     |  Picture / Format          |          |             |
|  |  SND Mode     |  Sleep / Timer             |          |             |
|  |  M/S          |  D.Menu / Top              |          |             |
|  |  |   |          |             |
|  |  |   |          |             |

