













































































Original	Replacement	Original	Replacement
 Power	 Power	 Language	 Dual
 Mute	 Mute	 Favourite	 Pre Ch
 DVB / Analog	 TV/R	 Cancel / Exit	 Exit
 Multi Media	 Media	 Menu	 Menu
 AV	 AV	 Aspect	 Format
 Normal	 Smart	 Audio I / II	 Shift + Dual
 Vol +	 Vol +	 Recall	 Back
 Vol -	 Vol -	 S.Effect	 Options
 PR/Page +	 Ch +	 1	 1
 PR/Page -	 Ch -	 2	 2
 Up	 Up	 3	 3
 Left	 Left	 4	 4
 OK / Select	 Ok	 5	 5
 Right	 Right	 6	 6
 Down	 Down	 7	 7
 Guide	 Guide	 8	 8
 Subtitle	 Subt	 9	 9





Original		Replacement	
	0		0
	Still		Pause
	Sleep		Sleep
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text		Text
	Reveal		List
	T.Cancel		Shift + Exit
	Size		Eject
	S-Code		Shift + Subt
	Hold		Stop
	Mix		Shift + Text
	Index		Info
	P.Mode		Shift + Format
	P.Still / P.Size		Shift + Pause

Original		Replacement	
	P.Swap		Shift + Back
	P.Input		Shift + AV
	P.PR +		Shift + Ch +
	P.PR -		Shift + Ch -

