








Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Source/[≡]	 AV
 Normal/OK/[≡i]	 OK
 PR+	 Ch +
 Up	 Up
 Down	 Down
 PR-	 Ch -

Original	Replacement
 Right/[≡o]	 Right
 Vol+	 Vol +
 Vol-	 Vol -
 Left/[≡+]	 Left
 Menu	 Menu
 Mute	 Mute
 Recall/[≡?]	 Pre Ch
 Sleep/[≡◇]	 Sleep
 Red/Skip	 Red
 Green/Movie	 Green
 Yellow/Delete	 Yellow
 Blue/Mode	 Blue
 [≡]	 Text
 [≡x]	 TV/R

