



Original	Replacement	Original	Replacement
	Power		Power
	Tv/AV		AV
	TV/TXT		Text
	Cancel		Eject
	Reveal		Media
	DTV		Smart
	Hold		3D
	Size		Format
	Subpage		Shift + Subt
	Index		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	CH+		Ch +
	CH-		Ch -
	Menu		Menu
	Exit		Exit
	Vol+		Vol +
	Vol-		Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9





Original		Replacement		Original		Replacement	
	0		0				
	FAV		Pre Ch				
	Recall		Back				
	Picture		Shift + Format				
	Sound		Dual				
	Nicam/A2		D. Menu				
	Mute		Mute				
	Sleep		Sleep				
	Info		Info				
	Subtitle		Subt				
	Channel List		List				
	EPG		Guide				
	Tv/Radio		TV/R				

