








































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	[<>]		Format
	♪		Dual
	[ ]		3D
	PAT		Smart
	PIP Sel		Play
	PIP Pos		Pause
	PIP Size		Stop
	AV		AV
	PC		Media
	TV		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	OK / Freeze		6
	6		7
	7		8
	8		9
	9		0
	0		Eject
	Zoom		Pre Ch
	Swap		Back
	Swap		Ch -
	PR-		Ch +
	PR+		Vol -
	Vol-		Vol +
	Vol+		Up
	Up		Right
	Right		Down
	Down		Left
	Left		Ok
	OK / Freeze		





Original		Replacement		Original		Replacement	
	Info		Info				
	Menu		Menu				
	[+]		Options				
	[?]		D. Menu				
	[◆]		Subt				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text / Mix		Text				
	[≡x]		Exit				
	[≡≡]		Guide				

