







































































| Original | Replacement | Original | Replacement |
|---|---|--|--|
|  On |  Power |  Stop |  Stop / Hold |
|  Standby |  Shift + Power |  Mute |  Mute / Dimmer |
|  Home |  Shift + Menu / |  HDMI Link |  Smart / List |
|  Blank |  Display / Media |  Volume- |  Vol- |
|  HDMI 1 |  1 |  Volume+ |  Vol+ |
|  HDMI 2 |  2 |  Lens |  TV/Radio / |
|  P-in-P/Swap |  3 |  Color Mode |  Setup / OPT / |
|  PC |  Fav / Marker / PC |  Image Enh |  Sleep / Timer |
|  LAN |  5 |  Up |  Up |
|  Wireless HD |  6 |  Left |  Left |
|  << |  << / Tune- |  Enter |  OK |
|  Play |  Play / Slow |  Right |  Right |
|  >> |  >> / Tune+ |  Default |  Back / Return |
|  I<< |  I<< / Preset- |  Down |  Down |
|  Pause |  Pause / Step / Freeze |  Esc |  Exit / Cancel / Clear |
|  >>I |  >>I / Preset+ |  Menu |  Menu / Home |
|  Link Menu |  D.Menu / Top |  Memory |  Red / Netflix / Search |





| | Original | Replacement | | Original | Replacement |
|--|-----------|-------------|-----------------------------|----------|-------------|
| | Lens1 | Lens 1 | Green / APP / Repeat | | |
| | Lens2 | Lens 2 | Yellow / YouTube / Repeat | | |
| | Frame Int | Frame Int | Blue / Prime Video / Random | | |
| | RGBCMY | RGBCMY | Text / Goto | | |
| | Pattern | Pattern | Subtitle / EQ | | |
| | User | User | Info / Angle | | |
| | 3D Format | 3D Format | Picture / Format | | |
| | Aspect | Aspect | Zoom / Size | | |
| | Power Tv | Power Tv | Shift + OK | | |
| | Output Tv | Output Tv | Shift + AV / Input / RDS | | |
| | Input Tv | Input Tv | AV / Input / RDS | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

