

















Original	Replacement
	 Play / Slow
	 Mute / Dimmer
	 Power
	 Pause / Step / Freeze
	 Stop / Hold
	 Rec / Rec Mode
	 << / Tune-

Original	Replacement

