













































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SUBTL	 Subt
 TV / Sat	 AV
 16:9	 Format
 Sleep	 Sleep
 Up / CH+	 Up

Original	Replacement
 Up / CH+	 Ch +
 Down / CH-	 Down
 Down / CH-	 Ch -
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 OK	 Ok
 Menu	 Menu
 Exit	 Exit
 TXT	 Text
 EPG	 Guide
 Info	 Info
 Audio	 Dual
 M-P	 Smart
 Page+	 >>
 Page-	  <<





Original	Replacement	Original	Replacement
 Red / SAT	 Red		
 Green / Zoom	 Green		
 Green / Zoom	 Eject		
 Yellow / Pause	 Yellow		
 Yellow / Pause	 Pause		
 Blue / TV/Radio	 Blue		
 Blue / TV/Radio	 TV/R		
 FAV	 Pre Ch		
 Recall	 Back		

