



| Original   | Replacement   |
|--|---|
|  Power      |  Power               |
|  Source     |  AV / Input / RDS    |
|  1          |  1                   |
|  2          |  2                   |
|  3          |  3                   |
|  4          |  4                   |
|  5          |  5                   |
|  6          |  6                   |
|  7          |  7                   |
|  8         |  8                  |
|  9        |  9                 |
|  0        |  0                 |
|  [TV]     |  TV/Radio /        |
|  Internet |  Smart / List      |
|  ↔        |  Fav / Marker / PC |
|  Mute     |  Mute / Dimmer     |
|  Vol+     |  Vol+              |

| Original  | Replacement   |
|---|---|
|  Vol-    |  Vol-                  |
|  P+      |  CH+ / Page+           |
|  P-      |  CH- / Page-           |
|  OK      |  OK                    |
|  Menu    |  Menu / Home           |
|  Back    |  Back / Return         |
|  Exit    |  Exit / Cancel / Clear |
|  Q.Menu  |  D.Menu / Top          |
|  Up      |  Up                    |
|  Down   |  Down                 |
|  Right |  Right               |
|  Left  |  Left                |
|  i     |  Info / Angle        |
|  EPG   |  Guide / EPG / -/-   |
|  TXT   |  Text / Goto         |
|  Lang. |  Audio / Lang I/II   |
|  Subt. |  Subtitle / EQ       |





| Original  | Replacement | Original  | Replacement                 |
|---|-------------|---|-----------------------------|
|    | Red         |    | Red / Netflix / Search      |
|    | [>]         |    | Picture / Format            |
|    | [+]         |    | Zoom / Size                 |
|    | Green       |    | Green / APP / Repeat        |
|    | Yellow      |    | Yellow / YouTube / Repeat   |
|    | *1/O        |    | Shift + 1                   |
|    | *2/Q        |    | Shift + 2                   |
|    | Blue        |    | Blue / Prime Video / Random |
|    | Rec         |    | Rec / Rec Mode              |
|    | Play        |    | Play / Slow                 |
|   | Pause       |   | Pause / Step / Freeze       |
|  | >>          |  | >> / Tune+                  |
|  | <<          |  | << / Tune-                  |
|  | Stop        |  | Stop / Hold                 |
|   |             |   |                             |
|   |             |   |                             |
|   |             |   |                             |
|   |             |   |                             |

