






































































Original	Replacement	Original	Replacement
Power	 Power	0	 0
TV Set Power	 +  Shift + Power	Recall	 Back
TV Set V +	 Vol +	Audio	 Dual
TV Set V -	 Vol -	Menu	 Menu
Mute	 Mute	Exit	 Exit
TV Mode	 Options	Up	 Up
TV / Rad	 TV/R	Right	 Right
Find	 Media	Down	 Down
1	 1	Left	 Left
2	 2	OK	 Ok
3	 3	Sat	 AV
4	 4	Fav	 Pre Ch
5	 5	PG +	 Ch +
6	 6	PG -	 Ch -
7	 7	YouTube	 Smart
8	 8	Play / PauInfo	 Info
9	 9	EPG	 Guide







Original	Replacement	Original	Replacement
Play / Pause	 Play		
Play / Pause	 Pause		
<< FB	 <<		
>> FF	 >>		
Stop	 Stop		
I<< Prev	 I<<		
>>I Next	 >>I		
Sleep	 Sleep		
Sub-T	 Subt		
Text	 Text		
Rec	 Rec		
Red / IPTV	 Red		
Green / Video	 Green		
Yellow / PVR	 Yellow		
Blue / Timer	 Blue		



Original	Replacement	Original	Replacement
Power		Text	 Text
Mute		PG+	 Ch +
Menu		PG-	 Ch -
Exit		Up	 Up
1		Left	 Left
2		OK	 Ok
3		Right	 Right
4		Down	 Down
5		Recall	 Back
6		Sleep	 Sleep
7		Find	 Shift + TV/R
8		TV / Rad	 TV/R
9		Info	 Info
0		EPG	 Guide
SAT		FAV	 Pre Ch
TV Mode		YouTube	 Media
S.Mode		Red / M/P	 Red



Original	Replacement	Original	Replacement
Green / Video	 Green		
Yellow / PVR	 Yellow		
Blue / Timer	 Blue		
Audio	 Dual		
Subtitle	 Subt		
Stop	 Stop		
Rec	 Rec		
Play/Pause	 Play		
Play/Pause	 Pause		

