



























































| Original | Replacement |
|---|--|
|  Power |  Power |
|  Power Tv |  Shift + Power |
|  DVD |  Shift + 2 |
|  HDD |  Shift + 7 |
|  Open/Close |  Eject / Surround |
|  AV Input Tv |  Shift + AV / Input / RDS |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  PR+ Tv |  Shift + CH+ / |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  PR- Tv |  Shift + CH- / |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |

| Original | Replacement |
|---|---|
|  Vol+ Tv |  Vol+ |
|  Rec |  Rec / Rec Mode |
|  0 |  0 |
|  AV Input |  AV / Input / RDS |
|  Vol- Tv |  Vol- |
|  |  << / Tune- |
|  |  >> / Tune+ |
|  |  I<< / Preset- |
|  |  >>I / Preset+ |
|  Pause |  Pause / Step / Freeze |
|  Play |  Play / Slow |
|  Stop |  Stop / Hold |
|  Home |  Menu / Home |
|  |  Up |
|  Menu List |  D.Menu / Top |
|  |  Left |
|  Enter |  OK |





| Original | Replacement |
|----------|-----------------------------|
| | Right |
| | Back / Return |
| | Down |
| | Display / Media |
| | Guide / EPG / -/-- |
| | CH- / Page- |
| | CH+ / Page+ |
| | Smart / List |
| | Red / Netflix / Search |
| | Green / APP / Repeat |
| | Yellow / YouTube / Repeat |
| | Subtitle / EQ |
| | Blue / Prime Video / Random |
| | Text / Goto |
| | Audio / Lang I/II |
| | Sound / Title |
| | Fav / Marker / PC |

| Original | Replacement |
|----------|-----------------------|
| | Exit / Cancel / Clear |
| | Sleep / Timer |
| | Shift + 1 |

