











































































































































| Original | Replacement | Original | Replacement |
|---|----------------|---|----------------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | AV/CL |  | AV / Input / RDS |
|  | Zoom |  | Zoom / Size |
|  | [...]/Subtitle |  | Subtitle / EQ |
|  | Audio/Language |  | Audio / Lang I/II |
|  | ◀/Camera |  | Shift + Info / Angle |
|  | ? |  | Setup / OPT / |
|  | ECO |  | Display / Media |
|  | CEC |  | Smart / List |
|  | Mute |  | Mute / Dimmer |
|  | i |  | Info / Angle |
|  | Z/Back |  | Back / Return |
|  | PR+ |  | CH+ / Page+ |
|  | Up |  | Up |
|  | Vol- |  | Vol- |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Vol+ |  | Vol+ |
|  | Down |  | Down |
|  | PR- |  | CH- / Page- |
|  | TVG/Top Menu |  | Guide / EPG / -/-- |
|  | TVG/Top Menu |  | D.Menu / Top |
|  | TXT/Menu |  | Text / Goto |








































































| Original | Replacement | Original | Replacement |
|---|----------------|---|----------------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | AV/CL |  | AV / Input / RDS |
|  | Zoom |  | Zoom / Size |
|  | [...]/Subtitle |  | Subtitle / EQ |
|  | Audio/Language |  | Audio / Lang I/II |
|  | ◀/Camera |  +  | Shift + Info / Angle |
|  | ? |  | Setup / OPT / |
|  | ECO |  | Display / Media |
|  | CEC |  | Smart / List |
|  | Mute |  | Mute / Dimmer |
|  | i |  | Info / Angle |
|  | Z/Back |  | Back / Return |
|  | PR+ |  | CH+ / Page+ |
|  | Up |  | Up |
|  | Vol- |  | Vol- |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Vol+ |  | Vol+ |
|  | Down |  | Down |
|  | PR- |  | CH- / Page- |
|  | TVG/Top Menu |  | Guide / EPG / -/-- |
|  | TVG/Top Menu |  | D.Menu / Top |
|  | TXT/Menu |  | Menu / Home |

































| Original | Replacement | Original | Replacement |
|---|----------------|---|----------------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | AV/CL |  | AV / Input / RDS |
|  | Zoom |  | Zoom / Size |
|  | [...]/Subtitle |  | Subtitle / EQ |
|  | Audio/Language |  | Audio / Lang I/II |
|  | ◀/Camera |  | Shift + Info / Angle |
|  | ? |  | Setup / OPT / |
|  | ECO |  | Display / Media |
|  | CEC |  | Smart / List |
|  | Mute |  | Mute / Dimmer |
|  | i |  | Info / Angle |
|  | Z/Back |  | Back / Return |
|  | PR+ |  | CH+ / Page+ |
|  | Up |  | Up |
|  | Vol- |  | Vol- |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Vol+ |  | Vol+ |
|  | Down |  | Down |
|  | PR- |  | CH- / Page- |
|  | TVG/Top Menu |  | Guide / EPG / -/-- |
|  | TVG/Top Menu |  | D.Menu / Top |
|  | TXT/Menu |  | Text / Goto |











































| Original | Replacement | Original | Replacement |
|--|---|----------|-------------|
|  TXT/Menu |  Menu / Home | | |
|  Red |  Red / Netflix / Search | | |
|  Green |  Green / APP / Repeat | | |
|  Yellow |  Yellow / YouTube / Repeat | | |
|  Blue |  Blue / Prime Video / Random | | |
|  [<>] |  Shift + Zoom / | | |
|  Rec/ > |  Rec / Rec Mode | | |
|  Play |  Play / Slow | | |
|  Pause |  Pause / Step / Freeze | | |
|  Stop |  Stop / Hold | | |
|  < |  << / Preset- | | |
|  > |  >> / Preset+ | | |
|  << |  << / Tune- | | |
|  >> |  >> / Tune+ | | |
| | | | |
| | | | |
| | | | |





| Original | Replacement |
|--|---|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  AV/CL |  AV / Input / RDS |
|  Zoom |  Zoom / Size |
|  [...] / Subtitle |  Subtitle / EQ |
|  Audio / Language |  Audio / Lang I / II |
|  ◀ / Camera |  Shift + Info / Angle |
|  ? |  Setup / OPT / |

| Original | Replacement |
|--|--|
|  ECO |  Display / Media |
|  CEC |  Smart / List |
|  Mute |  Mute / Dimmer |
|  i |  Info / Angle |
|  Z / Back |  Back / Return |
|  PR+ |  CH+ / Page+ |
|  Up |  Up |
|  Vol- |  Vol- |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Vol+ |  Vol+ |
|  Down |  Down |
|  PR- |  CH- / Page- |
|  TVG / Top Menu |  Guide / EPG / -/-- |
|  TVG / Top Menu |  D.Menu / Top |
|  TXT / Menu |  Text / Goto |



