













































































































| Original | | Replacement | | Original | | Replacement | |
|---|----------|---|---------------------------|---|-------|---|-----------------------|
|  | Power |  | Power |  | Menu |  | Menu / Home |
|  | Mute |  | Mute / Dimmer |  | Exit |  | Exit / Cancel / Clear |
|  | Nicam/A2 |  | Shift + Audio / Lang I/II |  | 1 |  | 1 |
|  | Sleep |  | Sleep / Timer |  | 2 |  | 2 |
|  | Aspect |  | Zoom / Size |  | 3 |  | 3 |
|  | USB/CR |  | Shift + 8 |  | 4 |  | 4 |
|  | Display |  | Display / Media |  | 5 |  | 5 |
|  | Auto |  | Smart / List |  | 6 |  | 6 |
|  | PMode |  | Picture / Format |  | 7 |  | 7 |
|  | SMode |  | Sound / Title |  | 8 |  | 8 |
|  | DTV |  | D.Menu / Top |  | 9 |  | 9 |
|  | Source |  | AV / Input / RDS |  | 0 |  | 0 |
|  | Up |  | Up |  | -/- |  | Guide / EPG / -/- |
|  | Left |  | Left |  | Back |  | Back / Return |
|  | Enter |  | OK |  | CH+ |  | CH+ / Page+ |
|  | Right |  | Right |  | Info |  | Info / Angle |
|  | Down |  | Down |  | Audio |  | Audio / Lang I/II |





| Original | Replacement |
|--|--|
|  Vol+ |  Vol+ |
|  CH- |  CH- / Page- |
|  FAV |  Fav / Marker / PC |
|  Tv/Radio |  TV/Radio / |
|  Vol- |  Vol- |
|  Text |  Text / Goto |
|  Play |  Play / Slow |
|  Pause |  Pause / Step / Freeze |
|  Stop/EPG |  Stop / Hold |
|  Subtitle |  Subtitle / EQ |
|  Rec/Hold |  Rec / Rec Mode |
|  <</Index |  << / Tune- |
|  >>/Size |  >> / Tune+ |
|  <</Reveal |  << / Preset- |
|  >> /Sbpage |  >> / Preset+ |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |

| Original | Replacement |
|--|---|
|  Yellow |  Yellow / YouTube / Repeat |
|  Cyan |  Blue / Prime Video / Random |

