











































































































































Original	Replacement	Original	Replacement
 On	 Power	 Digital	 Pre Ch
 Standby	 Shift + Power	 Page Up	 Ch +
 ID 1	 Red	 Page Down	 Ch -
 ID 2	 Green	 Magnify On	 Smart
 ID 3	 Yellow	 Magnify Off	 Media
 ID 4	 Blue	 Vol+	 Vol +
 Computer 1	 1	 Vol-	 Vol -
 Computer 2	 2	 AV Mute	 Mute
 Computer 3	 3	 Freeze	 Pause
 LAN	 4	 F5	 Text
 USB Type A	 5	 Reset	 AV
 USB Type B	 6	 Menu	 Menu
 Component	 7	 Up	 Up
 S.Video	 8	 Down	 Down
 Video	 9	 Right	 Right
 HDMI 1	 Guide	 Left	 Left
 HDMI 2	 0	 Enter	 Ok









































































Original	Replacement	Original	Replacement
 On	 Power	 Digital	 Pre Ch
 Standby	 Shift + Power	 Page Up	 Ch +
 ID 1	 Red	 Page Down	 Ch -
 ID 2	 Green	 Magnify On	 Smart
 ID 3	 Yellow	 Magnify Off	 Media
 ID 4	 Blue	 Vol+	 Vol +
 Computer 1	 1	 Vol-	 Vol -
 Computer 2	 2	 AV Mute	 Mute
 Computer 3	 3	 Freeze	 Pause
 LAN	 4	 F5	 Text
 USB Type A	 5	 Reset	 AV
 USB Type B	 6	 Menu	 Menu
 Component	 7	 Up	 Up
 S.Video	 8	 Down	 Down
 Video	 9	 Right	 Right
 HDMI 1	 Guide	 Left	 Left
 HDMI 2	 0	 Enter	 Ok









































































Original	Replacement	Original	Replacement
 On	 Power	 Digital	 Pre Ch
 Standby	 Shift + Power	 Page Up	 Ch +
 ID 1	 Red	 Page Down	 Ch -
 ID 2	 Green	 Magnify On	 Smart
 ID 3	 Yellow	 Magnify Off	 Media
 ID 4	 Blue	 Vol+	 Vol +
 Computer 1	 1	 Vol-	 Vol -
 Computer 2	 2	 AV Mute	 Mute
 Computer 3	 3	 Freeze	 Pause
 LAN	 4	 F5	 Text
 USB Type A	 5	 Reset	 AV
 USB Type B	 6	 Menu	 Menu
 Component	 7	 Up	 Up
 S.Video	 8	 Down	 Down
 Video	 9	 Right	 Right
 HDMI 1	 Guide	 Left	 Left
 HDMI 2	 0	 Enter	 Ok





Original	Replacement	Original	Replacement
 On	 Power	 Digital	 Pre Ch
 Standby	 Shift + Power	 Page Up	 Ch +
 ID 1	 Red	 Page Down	 Ch -
 ID 2	 Green	 Magnify On	 Smart
 ID 3	 Yellow	 Magnify Off	 Media
 ID 4	 Blue	 Vol+	 Vol +
 Computer 1	 1	 Vol-	 Vol -
 Computer 2	 2	 AV Mute	 Mute
 Computer 3	 3	 Freeze	 Pause
 LAN	 4	 F5	 Text
 USB Type A	 5	 Reset	 AV
 USB Type B	 6	 Menu	 Menu
 Component	 7	 Up	 Up
 S.Video	 8	 Down	 Down
 Video	 9	 Right	 Right
 HDMI 1	 Guide	 Left	 Left
 HDMI 2	 0	 Enter	 Ok



