



Original	Replacement	Original	Replacement
 Power	 Power	 7	 7
 Mute	 Mute	 8	 8
 Audio	 Dual	 9	 9
 TV / STB	 Shift + TV/R	 0	 0
 TV / R	 TV/R	 PGUP	 Vol +
 Sleep	 Sleep	 PGDN	 Vol -
 SUB	 Subt	 SAT	 Shift + AV
 TXT	 Text	 FAV +	 Ch +
 Multi	 Smart	 FAV -	 Ch -
 P / N	 Shift + 1	 EPG	 Guide
 Recall	 Pre Ch	 Fav	 Shift + Pre Ch
 1	 1	 Up / CH+	 Up
 2	 2	 Right / Vol+	 Right
 3	 3	 Down / CH-	 Down
 4	 4	 Left / Vol-	 Left
 5	 5	 OK	 Ok
 6	 6	 Menu	 Menu





Original	Replacement
Exit	Exit
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Pause	Pause
Zoom	Eject
Edit	Format
Info	Info
USB	AV
MP3	Media
JPEG	Shift + Media
PVR List	List
PIP	Shift + Ok
A - B	Back
T.S.	Shift + 2
Goto	Options

Original	Replacement
Stop	Stop
Rec	Rec
<<	<<
>>	>>
Play / Pause	Play
> <	Shift + Pause
<<	<<
>>	>>

