



| Original  | Replacement | Original  | Replacement |
|---|-------------|---|-------------|
|      | Power       |      | Power       |
|      | Red         |      | Red         |
|      | Green       |      | Green       |
|      | Yellow      |      | Yellow      |
|      | Blue        |      | Blue        |
|      | TV/SAT      |      | Smart       |
|      | TV/月        |      | TV/R        |
|      | Zoom        |      | Eject       |
|      | Pause       |      | Pause       |
|      | Audio       |      | Dual        |
|     | EPG         |     | Guide       |
|    | SubT        |    | Subt        |
|    | Text        |    | Text        |
|    | Exit        |    | Exit        |
|    | Menu        |    | Menu        |
|    | M/P         |    | Media       |
|    | Mute        |    | Mute        |
|    | Up/CH+      |    | Up          |
|    | Down/CH-    |    | Down        |
|    | Right       |    | Right       |
|    | Left        |    | Left        |
|    | OK          |    | Ok          |
|    | Vol+        |    | Vol +       |
|    | Vol-        |    | Vol -       |
|    | Recall      |    | Back        |
|    | FAV         |    | Pre Ch      |
|    | P+          |    | Ch +        |
|   | P-          |   | Ch -        |
|  | 1           |  | 1           |
|  | 2           |  | 2           |
|  | 3           |  | 3           |
|  | 4           |  | 4           |
|  | 5           |  | 5           |
|  | 6           |  | 6           |



