















































| Original   | Replacement  |
|--|--|
|  Power  |  Power                          |
|  Source |  AV / Input / RDS               |
|  1      |  1                              |
|  2      |  2                              |
|  3      |  3                              |
|  4      |  4                              |
|  5      |  5                              |
|  6      |  6                              |
|  7      |  7                              |
|  8     |  8                             |
|  9    |  9                            |
|  0    |  0                            |
|  EPG  |  Guide / EPG / -/--           |
|  Vol+ |  Vol+                         |
|  Vol- |  Vol-                         |
|  Mute |  Mute / Dimmer                |
|  APPS |  Shift + Green / APP / Repeat |

| Original  | Replacement  |
|---|--|
|  Home          |  Shift + Menu /               |
|  P+            |  CH+ / Page+                  |
|  P-            |  CH- / Page-                  |
|  Menu          |  Menu / Home                  |
|  i             |  Info / Angle                 |
|  Back          |  Back / Return                |
|  Mouse         |  Display / Media              |
|  Up            |  Up                           |
|  Down          |  Down                         |
|  Right        |  Right                       |
|  Left        |  Left                       |
|  OK          |  OK                         |
|  Netflix     |  Shift + Red / Netflix /    |
|  YouTube     |  Shift + Yellow / YouTube / |
|  prime video |  Shift + Blue / Prime       |
|  f           |  Smart / List               |
|  Red         |  Red / Netflix / Search     |





| Original  | Replacement                 | Original | Replacement |
|---|-----------------------------|----------|-------------|
|    | Green / APP / Repeat        |          |             |
|    | Yellow / YouTube / Repeat   |          |             |
|    | Blue / Prime Video / Random |          |             |
|    | Pause / Step / Freeze       |          |             |
|    | Play / Slow                 |          |             |
|    | Stop / Hold                 |          |             |
|    | << / Tune-                  |          |             |
|    | >> / Tune+                  |          |             |
|    | Text / Goto                 |          |             |
|   | Rec / Rec Mode              |          |             |
|  | I<< / Preset-               |          |             |
|  | >>I / Preset+               |          |             |
|  | Fav / Marker / PC           |          |             |
|  | Subtitle / EQ               |          |             |
|   |                             |          |             |
|   |                             |          |             |
|   |                             |          |             |

