

























































Original	Replacement
Power Audio	Power
Power Tv	+ Shift + Power
1	1
Dimmer	+ Shift + 1
2	2
Sleep	Sleep
3	3
A.Standby	+ Shift + 3
4	4
VFP	+ Shift + 4
5	5
Scan Mode	+ Shift + 5
6	6
3D Phonic	+ Shift + 7
7	7
8	8
.))	+ Shift + 8

Original	Replacement
9	9
DVD Level	+ Shift + 9
0	0
Page	List
10	Guide
+10	Pre Ch
Return	+ Shift + Back
Display	Info
Tv/Video	+ Shift + Media
Set	Media
Cancel	Exit
RDS Display	Smart
Top Menu/PG	D. Menu
Menu PL	Menu
TA/News/Info	+ Shift + Info
Tv CH+	Ch +
Up	Up













Original	Replacement
 Left	 Left
 PTV Select-	 +  Shift + Left
 Enter	 Ok
 PTV Select+	 +  Shift + Right
 Right	 Right
 Tv CH-	 Ch -
 Down	 Down
 Set Up	 Options
 On Screen	 3D
 PTV Search	 +  Shift + TV/R
 Play DVD/CD	 Play
 FM/AM	 TV/R
 AUX	 AV
 ←	 Back
 Repeat A-B	 +  Shift + Text
 Repeat	 Text
 FM/Play Mode	 +  Shift + Play

Original	Replacement
 Pause	 Pause
 Stop	 Stop
 <</Slow-	 <<
 >>/Slow+	 >>
 I<< Group/Title/Skip	 +  Shift + Ch -
 I<<	 I<<
 >>I Group/Title/Skip	 +  Shift + Ch +
 >>I	 >>I
 Audio	 Dual
 Subtitle	 Subt
 AHB Pro	 Blue
 Sound Turbo II	 Format
 Zoom	 Eject
 Angle	 Red
 Treble/Bass	 Green
 Vol+	 Vol +
 Tv Vol+	 +  Shift + Vol +





Original	Replacement	Original	Replacement
 Tv Vol-	 Shift + Vol -		
 Vol-	 Vol -		
 Clock/Timer	 Shift + AV		
 Fade Muting	 Mute		

