












































































































| Original  |            | Replacement   |         | Original  |                      | Replacement   |              |
|---|------------|---|---------|---|----------------------|---|--------------|
|    | Standby/On |    | Power   |    | I<<                  |    | I<<          |
|    | 1          |    | 1       |    | >>I                  |    | >>I          |
|    | 2          |    | 2       |    | Play                 |    | Play         |
|    | 3          |    | 3       |    | Stop                 |    | Stop         |
|    | 4          |    | 4       |    | <<                   |    | <<           |
|    | 5          |    | 5       |    | >>                   |    | >>           |
|    | 6          |    | 6       |    | Mute                 |    | Mute         |
|    | 7          |    | 7       |    | Prog+                |    | Ch +         |
|    | 8          |    | 8       |    | Prog-                |    | Ch -         |
|    | 9          |    | 9       |    | Vol+                 |    | Vol +        |
|   | 0          |   | 0       |   | Vol-                 |   | Vol -        |
|  | Tv/DVD     |  | TV/R    |  | Menu                 |  | Menu         |
|  | Open/Close |  | Eject   |  | Return               |  | Back         |
|  | DTV/Analog |  | Smart   |  | Exit                 |  | Exit         |
|  | Input Sel  |  | AV      |  | Title List/Disc Menu |  | Media        |
|  | Copy       |  | Options |  | Play List/Title Menu |  | Shift + Menu |
|  | Pause      |  | Pause   |  | Red                  |  | Red          |






































| Original   | Replacement  |
|--|--|
|  Green      |  Green            |
|  Yellow     |  Yellow           |
|  Blue       |  Blue             |
|  Guide      |  Guide            |
|  Info       |  Info             |
|  Subtitle   |  Subt             |
|  Text       |  Text             |
|  Tv/Radio   |  Sleep            |
|  FAV List   |  Pre Ch           |
|  Marker     |  Shift + Options |
|  Rec       |  Rec             |
|  Audio    |  Dual           |
|  Rec Mode |  Shift + Rec   |
|  Rec      |  Format         |
|  Repeat   |  Shift + Text  |
|  OK       |  Ok             |
|  Up       |  Up             |

| Original  | Replacement   |
|---|---|
|  Down  |  Down          |
|  Right |  Right         |
|  Left  |  Left          |
|  USB   |  Shift + Media |
|  Timer |  Shift + AV    |
|  HDD   |  Shift + Smart |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |
|   |   |









































































|   | Original      | Replacement   | Original | Replacement |
|---|---------------|---|----------|-------------|
|    | Input Sel     |    |          |             |
|    | 1             |    |          |             |
|    | 2             |    |          |             |
|    | 3             |    |          |             |
|    | 4             |    |          |             |
|    | 5             |    |          |             |
|    | 6             |    |          |             |
|    | 7             |    |          |             |
|    | 8             |    |          |             |
|    | 9             |    |          |             |
|   | 0             |   |          |             |
|  | Prog+         |  |          |             |
|  | Prog-         |  |          |             |
|  | Standby/On TV |  |          |             |
|  | Mute Tv       |  |          |             |
|  | Tv Vol+       |  |          |             |
|  | Tv Vol-       |  |          |             |





| Original   | Replacement   | Original   | Replacement  |
|--|---|--|--|
|  Standby/On   |  Power     |  I<<                    |  I<<            |
|  1            |  1         |  >>I                    |  >>I            |
|  2            |  2         |  Play                   |  Play           |
|  3            |  3         |  Stop                   |  Stop           |
|  4            |  4         |  <<                     |  <<             |
|  5            |  5         |  >>                     |  >>             |
|  6            |  6         |  Prog+                  |  Ch +           |
|  7            |  7         |  Prog-                  |  Ch -           |
|  8            |  8         |  Menu                   |  Menu           |
|  9            |  9         |  Return                 |  Back           |
|  0           |  0        |  Exit                  |  Exit          |
|  Tv/DVD     |  TV/R    |  Title List/Disc Menu |  Media        |
|  Open/Close |  Eject   |  Play List/Title Menu |  Shift + Menu |
|  DTV/Analog |  Smart   |  Red                  |  Red          |
|  Input Sel  |  AV      |  Green                |  Green        |
|  Copy       |  Options |  Yellow               |  Yellow       |
|  Pause      |  Pause   |  Blue                 |  Blue         |





| Original | Replacement                          | Original | Replacement                      |
|----------|--------------------------------------|----------|----------------------------------|
|          | GUIDE Guide                          |          | SHIFT + APP MEDIA Shift + Media  |
|          | DISPLAY INFO Info                    |          | SHIFT + TIMER AV Shift + AV      |
|          | AD SUBT Subt                         |          | SHIFT + HOME SMART Shift + Smart |
|          | REPEAT TEXT Text                     |          |                                  |
|          | E-MANUAL D.MENU D. Menu              |          |                                  |
|          | FAV PRE-CH Pre Ch                    |          |                                  |
|          | SHIFT + SETTINGS OPT Shift + Options |          |                                  |
|          | REC MODE REC Rec                     |          |                                  |
|          | SOUND DUAL Dual                      |          |                                  |
|          | SHIFT + REC MODE REC Shift + Rec     |          |                                  |
|          | PICTURE FORMAT Format                |          |                                  |
|          | SHIFT + REPEAT TEXT Shift + Text     |          |                                  |
|          | OK Ok                                |          |                                  |
|          | Up Up                                |          |                                  |
|          | Down Down                            |          |                                  |
|          | Right Right                          |          |                                  |
|          | Left Left                            |          |                                  |

