




































Original	Replacement
 Power	 Power
 TV	 TV/R
 Caption	 Subt
 Info	 Info
 [---]/Ratio	 3D
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List

Original	Replacement
 Flashbk	 D. Menu
 FAV	 Pre Ch
 Guide	 Guide
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 CH/Page+	 Ch +
 CH/Page-	 Ch -
 Picture	 Format
 Home	 Smart
 Sound	 Dual
 QMenu	 Menu
 SetUp	 Options
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original		Replacement		Original		Replacement	
	OK		Ok				
	Back		Back				
	Exit		Exit				
	SAP/*		Text				
	Sleep		Sleep				
	Stop		Stop				
	<<		<<				
	Play		Play				
	Pause		Pause				
	>>		>>				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

