









































































































Original	Replacement	Original	Replacement
 Power	 Power	 CH-	 CH- / Page-
 1	 1	 Home	 Menu / Home
 2	 2	 Source	 AV / Input / RDS
 3	 3	 Up	 Up
 4	 4	 Left	 Left
 5	 5	 Wheel Up	 >> / Tune+
 6	 6	 Right	 Right
 7	 7	 OK	 OK
 8	 8	 Wheel Down	 << / Tune-
 9	 9	 Down	 Down
 List/Menu	 Guide / EPG / -/--	 *	 Setup / OPT /
 List/Menu	 Smart / List	 Back	 Back / Return
 0/Quick Access	 0	 Red	 Red / Netflix / Search
 Vol+	 Vol+	 Green	 Green / APP / Repeat
 CH+	 CH+ / Page+	 Yellow	 Yellow / YouTube / Repeat
 Mute	 Mute / Dimmer	 Blue	 Blue / Prime Video / Random
 Vol-	 Vol-	 Netflix	 Shift + Red / Netflix / Search

Original	Replacement	Original	Replacement
 CH-	 CH- / Page-	 Home	 Menu / Home
 Source	 AV / Input / RDS	 Up	 Up
 Left	 Left	 Wheel Up	 >> / Tune+
 Right	 Right	 OK	 OK
 Wheel Down	 << / Tune-	 Down	 Down
 *	 Setup / OPT /	 Back	 Back / Return
 Red	 Red / Netflix / Search	 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat	 Blue	 Blue / Prime Video / Random
 Netflix	 Shift + Red / Netflix / Search		





Original	Replacement	Original	Replacement
 prime video	 +  SHIFT + Prime Video / RANDOM		
 Disney+	 +  SHIFT + APP / REPEAT		
 Rakuten TV	 +  SHIFT + YouTube / REPEAT A-B		

