




































































Original	Replacement
 Power	 Power
 Open/Close	 Eject / Surround
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Clear	 Exit / Cancel / Clear
 0	 0
 Repeat	 Shift + Green / APP /
 I<<	 I<< / Preset-
 <<	 << / Tune-
 >>	 >> / Tune+

Original	Replacement
 >>I	 >>I / Preset+
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Home	 Menu / Home
 Title/PopUp	 Sound / Title
 Title/PopUp	 Smart / List
 Menu/Info	 Info / Angle
 Up	 Up
 Right	 Right
 Left	 Left
 Enter	 OK
 Down	 Down
 Back	 Back / Return
 Subtitle	 Subtitle / EQ
 Menu Disc	 D.Menu / Top
 Red	 Red / Netflix / Search



