





































Original	Replacement
	 Power
	 Rec / Rec Mode
	 Red / Netflix / Search
	 I<< / Preset-
	 Green / APP / Repeat
	 Stop / Hold
	 Yellow / YouTube / Repeat
	 Play / Slow
	 Blue / Prime Video / Random
	 >>I / Preset+
	 AV / Input / RDS
	 Audio / Lang I/II
	 Picture / Format
	 Zoom / Size
	 Menu / Home
	 Text / Goto
	 Pause / Step / Freeze

Original	Replacement
	 Left
	 Up
	 Right
	 OK
	 Down
	 Vol+
	 Mute / Dimmer
	 CH+ / Page+
	 Vol-
	 Sound / Title
	 CH- / Page-
	 Smart / List
	 1
	 2
	 3
	 4
	 5


























Original	Replacement	Original	Replacement
	6		6
	7		7
	8		8
	9		9
	[i+]		Info / Angle
	0		0
	P<P		Fav / Marker / PC





Original	Replacement
	 Eject / Surround
	 Subtitle / EQ
	 Power
	 Rec / Rec Mode
	 I<< / Preset-
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Stop / Hold
	 Play / Slow
	 Yellow / YouTube / Repeat
	 >>I / Preset+
	 AV / Input / RDS
	 Audio / Lang I/II
	 Zoom / Size
	 Picture / Format
	 Menu / Home
	 Pause / Step / Freeze

Original	Replacement
	 Text / Goto
	 Left
	 Up
	 Right
	 OK
	 Down
	 Vol+
	 Mute / Dimmer
	 CH+ / Page+
	 Vol-
	 Sound / Title
	 CH- / Page-
	 Smart / List
	 1
	 2
	 3
	 4



































Original		Replacement	
	5		5
	6		6
	7		7
	8		8
	9		9
	[i+]		Info / Angle
	0		0
	P<P		Fav / Marker / PC

Original		Replacement	





Original	Replacement
 Power	 Power
 -O-	 Subtitle / EQ
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 AV/[?]	 AV / Input / RDS
 I-II/[≡ ≡]	 Audio / Lang I/II
 [<>]/[+]	 Zoom / Size
 Pause	 Pause / Step / Freeze
 [≡]	 Text / Goto
 Left	 Left
 Up	 Up
 Right	 Right
 OK	 OK
 Down	 Down
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+

Original	Replacement
 Vol-	 Vol-
 Smart J	 Sound / Title
 P-	 CH- / Page-
 Smart []	 Smart / List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 P<P	 Fav / Marker / PC

