







Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Mute		Mute		9		9
	Red		Red		0		0
	Green		Green		-/--		Guide
	Yellow		Yellow		Recall		Back
	Blue		Blue		Input		AV
	P.Mode		3D		Display		Info
	S.Mode		Dual		Up		Up
	Sleep		Sleep		Left		Left
	Aspect		Format		OK		Ok
	1		1		Right		Right
	2		2		Down		Down
	3		3		Menu		Menu
	4		4		Exit		Exit
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		TV/Radio		TV/R





Original	Replacement
 Audio	 List
 CH+	 Ch +
 CH-	 Ch -
 Play/Pause / Text	 Pause
 Play/Pause / Text	 Play
 Play/Pause / Text	 Text
 Stop / Size	 Stop
 << / Hold	 <<
 >> / Index	 >>
 I<< / Reveal	 I<<
 >>I / Subpage	 >>I
 Cancel	 Shift + Back
 Mix	 Options
 FAV-	 Shift + Down
 FAV+	 Shift + Up
 FAV	 Pre Ch
 Auto	 Smart

Original	Replacement
 Repeat	 Shift + Text
 Subtitle	 Subt

