







































































| Original | Replacement | Original | Replacement |
|---|--|---|---|
|  Standby |  Power |  Right |  Right |
|  Display |  Shift + Info |  Down |  Down |
|  Nicam / Eject |  Eject |  Source |  AV |
|  Mute |  Mute |  Exit |  Exit |
|  P.Mode |  Shift + Format |  1 |  1 |
|  S.Mode |  Shift + Dual |  2 |  2 |
|  Sleep |  Sleep |  3 |  3 |
|  Aspect |  Format |  4 |  4 |
|  Vol - |  Vol - |  5 |  5 |
|  Vol + |  Vol + |  6 |  6 |
|  CH - |  Ch - |  7 |  7 |
|  CH + |  Ch + |  8 |  8 |
|  LCD-Menu |  Menu |  9 |  9 |
|  DVD-Setup |  Options |  0 |  0 |
|  Up |  Up |  Recall |  Back |
|  Left |  Left |  Text / Audio |  Text |
|  Enter |  Ok |  Hold / A-B / Rec List |  Smart |





| Original | Replacement | Original | Replacement |
|---|---|---|---|
|  Rec |  Rec |  I> Step |  Shift + Pause |
|  Time Shift |  Media |  >> |  >>> |
|  Red / Repeat |  Red |  Subtitle |  Subt |
|  Red / Repeat |  Shift + Text |  EPG / Program |  Guide |
|  Green / Zoom |  Green |  FAV |  Pre Ch |
|  Green / Zoom |  Shift + Eject |  EPG / Program |  Shift + Sleep |
|  Yellow / Angle |  Yellow |  Info / Title |  Info |
|  Blue / Goto |  Blue | | |
|  Index / I<< |  I<< | | |
|  Size / Stop |  Stop | | |
|  Rev. / Play/Pause |  Play | | |
|  Rev. / Play/Pause |  Pause | | |
|  Sub.P / >>I |  >>I | | |
|  TV/Radio / << |  << | | |
|  TV/Radio / << |  TV/R | | |
|  Lang / Menu |  Dual | | |
|  Lang / Menu |  D. Menu | | |

