





























































Original	Replacement
 TV	 Shift + 1
 AV.SV	 AV / Input / RDS
 SCART1	 Shift + 3
 PC	 Shift + Fav / Marker / PC
 SCART2	 Shift + 2
 Mute	 Mute / Dimmer
 Up / P+	 Up
 Up / P+	 CH+ / Page+
 Exit	 Exit / Cancel / Clear
 Left / Vol-	 Left
 Left / Vol-	 Vol-
 Menu / Enter	 OK
 Menu / Enter	 Menu / Home
 Right / Vol+	 Right
 Right / Vol+	 Vol+
 Down / P-	 Down
 Down / P-	 CH- / Page-

Original	Replacement
 Text	 Text / Goto
 Red	 Red / Netflix / Search
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Green	 Green / APP / Repeat
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 +100	 Guide / EPG / -/-
 0	 0
 RTN	 Back / Return





Original	Replacement
RTN	Fav / Marker / PC
Sound	Sound / Title
PIP Source Up	+  Shift + Up
Display	Display / Media
PIP Position	+  Shift + Left
PIP On/Off	+  Shift + OK
PIP Size	+  Shift + Right
APC	D.Menu / Top
PIP Source	+  Shift + Down
ARC	Setup / OPT /
[ ]	Stop / Hold
[ ≡ i ]	Play / Slow
[ ↑ ↓ ]	>> / Tune+
[ ≡ ? ]	Pause / Step / Freeze
[ ⊙ ]	<< / Preset-
[ ≡ X ]	<< / Tune-
Sleep	Sleep / Timer

Original	Replacement
Reset	Smart / List
Power	Power

