



































Original	Replacement	Original	Replacement
On/Off	 Power	Menu Right	 Right
Audio Out	 Mute	Menu Down	 Down
Slow Down	 Back	Tracking+	 Vol +
F.Adv	 Exit	Next	 >>
Auto/Track	 List	Tracking-	 Vol -
Mon/TV	 Text	Audio	 Dual
Video/Go-To	 D. Menu	Prev.	 <<
Stop	 Stop	1	 1
Sp/Lp/Speed	 Format	2	 2
Slow/Dpss+	 Shift + Ch +	3	 3
Pause	 Pause	4	 4
Slow/Dpss-	 Shift + Ch -	5	 5
Menu	 Menu	6	 6
Menu Up	 Up	7	 7
Display	 Info	8	 8
T.Set/Clock	 Sleep	9	 9
Menu Left	 Left	Audio Dub	 Subt



Original	Replacement	Original	Replacement
-/--	 Guide	Timer/Record	 +  Shift + Info
0	 0	Rec. On/Off	 +  Shift + 5
Progr/C/CH	 Pre Ch	Counter Stop	 3D
Record	 Rec	Counter Reset	 +  Shift + 3D
Rewind	 <<	Mark Add/Del	 +  Shift + 7
F.Forward	 >>	Clear 00:00	 +  Shift + 9
Eject/Reverse	 +  Shift + Mute		
Encode	 Smart		
Play	 Play		
X2 Rew/Play	 +  Shift + <<		
Search Index	 +  Shift + TV/R		
Index Pict-	 Ch -		
Ch.Memo	 Media		
Index Pict+	 Ch +		
P.Back/R. + Play	 +  Shift + >>		
Skip/Search	 TV/R		
Input Source	 AV		

