












| Original | Replacement | Original | Replacement |
|---|--|--|--|
|  Power |  On |  Left |  Left |
|  Help |  OFF | | |
|  Pointer |  K.S. / PIP | | |
|  Magnify+ |  KS Up | | |
|  Magnify- |  KS Down | | |
|  Pic/Mute |  Mute / Focus | | |
|  Source |  SRC / Search | | |
|  Auto ADJ. |  Auto / Mode | | |
|  Menu |  Menu / Info | | |
|  Aspect |  Aspect / Re-Sync | | |
|  Enter |  OK | | |
|  Cancel |  Exit / Lamp | | |
|  Vol+ |  Vol + | | |
|  Vol- |  Vol - | | |
|  Up |  Up | | |
|  Down |  Down | | |
|  Right |  Right | | |

