















Original	Replacement	Original	Replacement
Power	Power	Up	Up
1	1	Left	Left
2	2	Right	Right
3	3	Down	Down
4	4	Red/M	Red / Netflix / Search
5	5	Green/Sound	Sound / Title
6	6	Green/Sound	Green / APP / Repeat
7	7	Yellow/Vision	Yellow / YouTube / Repeat
8	8	Blue/Menu	Blue / Prime Video / Random
9	9	Blue/Menu	Menu / Home
0	0	Text	Text / Goto
i	Info / Angle	Size	Zoom / Size
Mute	Mute / Dimmer	Stop	Stop / Hold
ideal	Smart / List		
Back	Back / Return		
TV	TV/Radio /		
TV	Shift + 1		












Original		Replacement		Original		Replacement	
	Power		Power		Up		Up
	1		1		Left		Left
	2		2		Right		Right
	3		3		Down		Down
	4		4		Red/M		Red / Netflix / Search
	5		5		Green/Sound		Audio / Lang I/II
	6		6		Green/Sound		Green / APP / Repeat
	7		7		Yellow/Vision		Yellow / YouTube / Repeat
	8		8		Blue/Menu		Blue / Prime Video / Random
	9		9		Blue/Menu		Menu / Home
	0		0		Text		Text / Goto
	i		Info / Angle		Size		Zoom / Size
	Mute		Mute / Dimmer		Stop		Stop / Hold
	ideal		Smart / List				
	Back		Back / Return				
	TV		TV/Radio /				
	TV		Shift + 1				







Original		Replacement		Original		Replacement	
	Power		Power		Up		Up
	1		1		Left		Left
	2		2		Right		Right
	3		3		Down		Down
	4		4		Red/M		Red / Netflix / Search
	5		5		Green/Sound		Green / APP / Repeat
	6		6		Green/Sound		Sound / Title
	7		7		Yellow/Vision		Yellow / YouTube / Repeat
	8		8		Blue/Menu		Blue / Prime Video / Random
	9		9		Blue/Menu		Menu / Home
	0		0		Text		Text / Goto
	i		Info / Angle		Size		Zoom / Size
	Mute		Mute / Dimmer		Stop		Stop / Hold
	ideal		Smart / List				
	Back		Back / Return				
	TV		TV/Radio /				
	TV		Shift + 1				

