







































































Original		Replacement		Original		Replacement	
	Power		Power		CH+		Ch +
	Mute		Mute		CH-		Ch -
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		OK		Ok
	6		6		Exit		Exit
	7		7		Text		Text
	8		8		Menu		Menu
	9		9		Aspect		3D
	0		0		Size		Format
	-/--		Guide		Sleep		Sleep
	Recall		Pre Ch		Media		Media
	Source		AV		Reveal		Options
	Vol+		Vol +		Info		Info
	Vol-		Vol -		Tv/Radio		TV/R





Original	Replacement	Original	Replacement
I/II/Audio	Dual		Shift + Text
Subtitle	Subt		
Play	Play		
Pause	Pause		
Stop	Stop		
Rec	Rec		
I<<	I<<		
>>I/Index	>>I		
<</Subpage	<<		
>>/Hold	>>		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
PIC Mode	Shift + Format		
S.Mode	Shift + Dual		
Rec Menu	Shift + Rec		

Original	Replacement
	Shift + Text

