
































































Original	Replacement
 Power	 Power
 Info	 Info / Angle
 Mute	 Mute / Dimmer
 I - II	 Audio / Lang I/II
 Fav	 Fav / Marker / PC
 AV / Source	 AV / Input / RDS
 TV / DTV	 TV/Radio /
 1	 1
 2	 2
 3	 3
 Red / Page+	 Red / Netflix / Search
 Red / Page+	 Shift + CH+ /
 4	 4
 5	 5
 6	 6
 Green / Page-	 Shift + CH- /
 Green / Page-	 Green / APP / Repeat

Original	Replacement
 7	 7
 8	 8
 9	 9
 Yellow	 Yellow / YouTube / Repeat
 -/-- / Exit	 Shift + Guide / EPG / -/--
 -/-- / Exit	 Exit / Cancel / Clear
 0	 0
 M	 Menu / Home
 Blue	 Blue / Prime Video / Random
 Up	 Up
 Left	 Left
 OK / Select	 OK
 Right	 Right
 Down	 Down
 P+	 CH+ / Page+
 P-	 CH- / Page-
 V-	 Vol-





Original		Replacement		Original		Replacement	
	V+		Vol+		Size / Wide		Zoom / Size
	Stop		Stop / Hold		Reveal / PIP		Shift + AV / Input / RDS
	Play		Play / Slow		Index / Guide		Guide / EPG / -/-
	Pause		Pause / Step / Freeze		Mix / PIP		Picture / Format
	LIB		Display / Media				
	Rec		Rec / Rec Mode				
	<<		<< / Tune-				
	>>		>> / Tune+				
	Time		Sleep / Timer				
	PIP-		I<< / Preset-				
	PIP+		>>I / Preset+				
	P<P / Swap		Back / Return				
	PP		Eject / Surround				
	Text		Text / Goto				
	Subpage		Subtitle / EQ				
	Hold		Shift + Stop /				
	Cancel		Shift + Exit / Cancel / Clear				

