







































































Original	Replacement	Original	Replacement
	Power		Power
	Picture		Format
	J/Sound		Dual
	Set Up		Menu
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	[+]		Info
	Tv/AV		AV
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[≡♦]/FP		TV/R
	[≡i]/Index		Smart
	[≡+]/Hold/Still		Options
	Tv/Text		Text
	Direct Tv Rec		Rec
	OIO		List
	Aspect		3D
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8



