



Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Last View		Pre Ch
	Radio/Tv		TV/R
	Internet		Smart
	Netflix		Media
	Rec		Rec
	Prog/Check		Sleep
	Play		Play
	>>		>>
	<<		<<
	Pause		Pause
	>>		>>
	<<<		<<<
	Exit		Exit
	i/Status		Info
	Return		Back
	Guide		Guide
	Function Menu		Menu
	Video Menu		D. Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left





Original	Replacement
OK	Ok
Option	Options
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Audio	Dual
Drive Select	List
Text	Text
STTL	Subt
+60s	3D
-10s	Format
Page/CH+	Ch +
Page/CH-	Ch -
Tv Vol+	Vol +
Tv Vol-	Vol -
AV Input Tv	AV

Original	Replacement
CH+ Tv	Shift + Ch +
CH- Tv	Shift + Ch -
Power Tv	Shift + Power

