





















































































Original		Replacement		Original		Replacement	
	Power		Power		Yellow		Yellow
	Input		AV		Blue		Blue
	i		Info		Vol+		Vol +
	[G]		Guide		Vol-		Vol -
	*1		Format		Mute		Mute
	Home		Smart		P+		Ch +
	Netflix		Media		P-		Ch -
	*2		3D		1		1
	Exit		Exit		2		2
	Back		Back		3		3
	Up		Up		4		4
	Down		Down		5		5
	Right		Right		6		6
	Left		Left		7		7
	OK		Ok		8		8
	Red		Red		9		9
	Green		Green		0		0





Original		Replacement		Original		Replacement	
	Lang		Dual				
	TXT		Text				
	<<		<<				
	Play		Play				
	>>		>>				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				

