



Original		Replacement		Original		Replacement	
	Power		Power		Mute		Mute
	TRK+		Shift + Right		PR+		Ch +
	TRK-		Shift + Left		PR-		Ch -
	Red/Pref.		Red		1		1
	Green/Showvie		Green		2		2
	Yellow/Info		Yellow		3		3
	Blue/Tv Time		Blue		4		4
	Violet/Text		Text		5		5
	Exit		Exit		6		6
	Menu		Menu		7		7
	Up/VPS		Up		8		8
	Down/Goto		Down		9		9
	Right/>>>I		Right		0/--		0
	Left/I<<		Left		AV		AV
	OK		Ok		>>/F.FWD		>>
	Vol+		Vol +		000		Media
	Vol-		Vol -		<</REW		<<



