



































Original	Replacement	Original	Replacement
	Power		Green
	Stop		Yellow
	Pause		Blue
	Rec		Info
	<<		Options
	Play		Back
	>>		Multiview
	[<>]		Up
	Search		Down
	*		Right
	Tv Guide		Left
	List		Netflix
	Sources		Media
	Smart Tv		Ok
	Home		Vol +
	Exit/tv		Vol -
	Red		Mute
			Ch +



