







































































Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Setup	 Setup / OPT /	 Movie	 Display / Media
 DTV	 D.Menu / Top	 Music	 Smart / List
 1	 1	 Photo	 Picture / Format
 2	 2	 Vol-	 Vol-
 3	 3	 Vol+	 Vol+
 HDMI/AV	 AV / Input / RDS	 Up	 Up
 4	 4	 Left	 Left
 5	 5	 Enter	 OK
 6	 6	 Right	 Right
 Disc	 Shift + 3	 Exit	 Exit / Cancel / Clear
 7	 7	 Down	 Down
 8	 8	 Home	 Menu / Home
 9	 9	 Edit	 Back / Return
 Rec	 Rec / Rec Mode	 Copy	 Shift + Smart / List
 EPG	 Guide / EPG / -/--	 Repeat	 Green / APP / Repeat
 TTX	 Text / Goto	 <<	 << / Tune-





Original	Replacement	Original	Replacement
 Play/Pause	 Play / Slow		
 I<<	 I<< / Preset-		
 >>	 >> / Tune+		
 Stop	 Stop / Hold		
 >>I	 >>I / Preset+		
 Audio	 Audio / Lang I/II		
 Sub-T	 Subtitle / EQ		
 FAV	 Fav / Marker / PC		
 Info	 Info / Angle		
 Mute	 Mute / Dimmer		
 DVD	 Shift + 2		
 Timer	 Sleep / Timer		
 T/R	 Zoom / Size		

