










































































| Original | Replacement | Original | Replacement |
|---|---|---|--|
|  Power |  Power |  4 |  4 |
|  Red / ↑ |  Red / Netflix / Search |  5 |  5 |
|  green / ↓ |  Green / APP / Repeat |  6 |  6 |
|  Yellow |  Yellow / YouTube / Repeat |  7 |  7 |
|  Blue |  Blue / Prime Video / Random |  8 |  8 |
|  Exit |  Exit / Cancel / Clear |  9 |  9 |
|  [≡o] |  Sleep / Timer |  P<P/Swap |  Picture / Format |
|  [≡+] |  Stop / Hold |  0 |  0 |
|  [≡x] |  Smart / List |  -/-- |  Shift + Guide / EPG / -/-- |
|  [≡] |  Text / Goto |  Vol- |  Vol- |
|  [/≡] |  Setup / OPT / |  Vol+ |  Vol+ |
|  [≡♦]/[+]/Wide |  Menu / Home |  Mute |  Mute / Dimmer |
|  [≡?] |  Shift + Info / Angle |  P- |  CH- / Page- |
|  [≡i]/Guide |  Guide / EPG / -/-- |  P+ |  CH+ / Page+ |
|  1 |  1 |  [i]/Info |  Info / Angle |
|  2 |  2 |  Tv/DTV |  TV/Radio / |
|  3 |  3 |  [AV]/Source |  AV / Input / RDS |





| Original | Replacement | Original | Replacement |
|---|---|----------|-------------|
|  |  Audio / Lang I/II | | |
|  |  Back / Return | | |
|  |  Up | | |
|  |  Left | | |
|  |  OK | | |
|  |  Right | | |
|  |  D.Menu / Top | | |
|  |  Down | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

