







































































Original		Replacement		Original		Replacement	
	Power		Power		Guide		Guide
	Source		AV		Tools		Options
	1		1		Smart Hub		Smart
	2		2		Info		Info
	3		3		Return		Back
	4		4		Exit		Exit
	5		5		Enter		Ok
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		Red		Red
	TTX/MIX		Text		Green		Green
	PRE-CH		Pre Ch		Yellow		Yellow
	Mute		Mute		Blue		Blue
	CH List		List		Social Tv		Media
	Menu		Menu		3D		3D





Original	Replacement	Original	Replacement
P.SIZE	P.Size	PICTURE FORMAT	Format
AD/SUBT.	AD/Subt.	AD SUBT	Subt
SEARCH	Search	SEARCH TV/R	TV/R
E-MANUAL	E-Manual	E-MANUAL D.MENU	D. Menu
Play	Play	PLAY MODE	Play
Rec	Rec	REC MODE	Rec
Stop	Stop	Stop	Stop
Pause	Pause	Pause	Pause
<</ <<	<</ <<	<<	<<
>>/>>	>>/>>	>>	>>
Vol+	Vol +	VOL +	Vol +
Vol-	Vol -	VOL -	Vol -
P+	Ch +	+ CH	Ch +
P-	Ch -	- CH	Ch -

