



	Original	Replacement		Original	Replacement
	 Power	 Power		 Ch.List	 List
	 Source	 AV		 P +	 Ch +
	 1	 1		 P -	 Ch -
	 2	 2		 Media.P	 Media
	 3	 3		 Menu	 Menu
	 4	 4		 Guide	 Guide
	 5	 5		 Tools	 Options
	 6	 6		 Info	 Info
	 7	 7		 Up	 Up
	 8	 8		 Right	 Right
	 9	 9		 Down	 Down
	 0	 0		 Left	 Left
	 TTX/MIX	 Text		 Enter	 Ok
	 PRE-CH	 Pre Ch		 Return	 Back
	 Vol+	 Vol +		 Exit	 Exit
	 Vol-	 Vol -		 Red	 Red
	 Mute	 Mute		 Green	 Green





Original		Replacement		Original		Replacement	
	Yellow		Yellow				
	Blue		Blue				
	P.Mode		Shift + Format				
	Dual I/II		Dual				
	3D		3D				
	AD		Shift + Subt				
	P.Size		Format				
	Subt.		Subt				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

