



Original	Replacement	Original	Replacement
Power	Power	CH+	Ch +
Source	AV	CH-	Ch -
Sleep	Sleep	Down	Down
Mute	Mute	Right	Right
1	1	Left	Left
2	2	Vol-	Vol -
3	3	Vol+	Vol +
4	4	Enter	Ok
5	5	Red	Red
6	6	Green	Green
7	7	Yellow	Yellow
8	8	Blue	Blue
9	9	Info	Info
0	0	EPG	Guide
-/--	Shift + Guide	Menu	Menu
Recall	Pre Ch	Nicam	Media
Up	Up	FAV+	>>





Original	Replacement
FAV-	←←
TXT	REPEAT TEXT
EDITOR/GROUP	SETTINGS OPT
INDEX	RETURN BACK
LANG/AUDIO	SOUND DUAL
TV/RADIO	SEARCH TV/R
SUBTITLE	AD SUBT
SUBPAGE	SHIFT + AD SUBT
SIZE	PICTURE FORMAT
HOLD	ECO 3D
STILL	CLEAR EXIT
P.MODE	SHIFT + PICTURE FORMAT
S.MODE	SHIFT + SOUND DUAL

Original	Replacement

