
























































Original	Replacement	Original	Replacement
 Power	 Power	 Dev.List	 Media
 Mute	 Mute	 EPG	 Guide
 1	 1	 Subtitle	 Subt
 2	 2	 Text	 Text
 3	 3	 Auto	 Options
 4	 4	 Menu	 Menu
 5	 5	 Zoom	 Eject
 6	 6	 Info	 Info
 7	 7	 Exit	 Exit
 8	 8	 Up	 Up
 9	 9	 Down	 Down
 0	 0	 Right	 Right
 Lang	 Dual	 Left	 Left
 Time Shift	 Smart	 CH+	 Ch +
 Tv/Radio	 TV/R	 CH-	 Ch -
 FAV	 Shift + Pre Ch	 Vol+	 Vol +
 Recall	 Pre Ch	 Vol-	 Vol -





Original	Replacement	Original	Replacement
 Enter	 Ok		
 Filelist	 AV		
 Rec	 Rec		
 Stop	 Stop		
 Play	 Play		
 Pause	 Pause		
 <<	 <<		
 >>	 >>		
 I<<	 I<<		
 >>I	 >>I		
 Red/FAV./Daily	 Red		
 Green/Del./Weekl	 Green		
 Yellow/Movie/P.Inf	 Yellow		
 Blue/Lock/Timer	 Blue		

