





















































	Original	Replacement		Original	Replacement
	Standby		Power		Down
	PVR Rec		Rec		Right
	PVR List		List		Left
	Mute		Mute		Ok
	EPG		Guide		Vol +
	Audio		Dual		Vol -
	Info		Info		1
	DTV/VCR		Smart		2
	TTX		Text		3
	Subtitle		Subt		4
	Menu		Menu		5
	Exit		Exit		6
	Tv/Radio		TV/R		7
	Favourite		Pre Ch		8
	CH+		Ch +		9
	CH-		Ch -		0
	Up		Up		Recall
					Back























































	Original	Replacement	Original	Replacement
	Goto	3D		
	<<	<<		
	>>	>>		
	I<<	I<<		
	>>I	>>I		
	Play	Play		
	Pause	Pause		
	Stop	Stop		
	RPT	Media		
	Red	A Red		
	Green	B Green		
	Yellow	C Yellow		
	Blue	D Blue		





	Original	Replacement		Original	Replacement
	Standby		Power		Down
	PVR Rec		Rec		Right
	PVR List		List		Left
	Mute		Mute		Ok
	EPG		Guide		Vol +
	Audio		Dual		Vol -
	Info		Info		1
	DTV/VCR		Smart		2
	TTX		Text		3
	Subtitle		Subt		4
	Menu		Menu		5
	Exit		Exit		6
	Tv/Radio		TV/R		7
	Favourite		Pre Ch		8
	CH+		Ch +		9
	CH-		Ch -		0
	Up		Up		Recall
					Back





Original	Replacement	Original	Replacement
GOTO	3D		
<<<	<<<		
>>>	>>>		
I<<<	I<<<		
>>I	>>I		
Play	Play		
Pause	Pause		
Stop	Stop		
RPT	Media		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		

