

































































































Original	Replacement	Original	Replacement
 Standby	 Power	 0	 0
 Prog	 Sleep	 10+	 Guide
 Display	 Info	 Time	 AV
 Open / Close	 Eject	 Setup	 Options
 N/P	 Red	 Repeat	 Text
 Subtitle	 Subt	 Up	 Up
 Language	 Dual	 Left	 Left
 Angle	 Format	 Play / Enter	 Ok
 1	 1	 Play / Enter	 Play
 2	 2	 Right	 Right
 3	 3	 Down	 Down
 4	 4	 Func+	 Vol +
 5	 5	 Func-	 Vol -
 6	 6	 Stop	 Stop
 7	 7	 Karaoke	 Green
 8	 8	 Zoom	 Shift + Eject
 9	 9	 Mic	 List





Original	Replacement	Original	Replacement
 Resume	 Ch +		
 PBC	 Yellow		
 Title	 Blue		
 A/B	 TV/R		
 Menu	 Menu		
 I<< Prev	 I<<		
 Next >>I	 >>I		
 << REV	 <<		
 Fwd >>	 >>		
 Slow	 Ch -		
 Pause	 Pause		
 Func Select	 Smart		
 Mute	 Mute		
 Step	 Back		
 Mode	 D. Menu		
 PScan / Normal	 Media		

